

Globe valves, 2-way, with external thread

- for open and closed cold and warm water systems
- for modulating water-side control of air handling units and heating systems



Type overview

Туре	k vs [m ³ /h]	DN Stroke [mm]		Sv
H411B	0.63	15	15	>50
H412B	1	15	15	>50
H413B	1.6	15	15	>50
H414B	2.5	15	15	>50
H415B	4	15	15	>50
H420B	6.3	20	15	>100
H425B	10	25	15	>100
H432B	16	32	15	>100
H440B	25	40	15	>100
H450B	40	50	15	>100

Tacl	hnical	data

Func	tional	data
runc	แบบส	uala

Flow media	Cold and warm water,
	water with max. 50% volume of glycol
Temperature of medium	(-10°C) +5°C +120°C (-10°C on request)
Rated pressure ps	1600 kPa (PN16)
Flow characteristic	Control path A – AB: equal percentage (to VDI/VDE 2173) $n(gl) = 3$, optimized in the opening range
Rangeability S _v	See «Type overview»
Leakage rate	Control path A – AB: leakage class III (DIN EN 1349 and DIN EN 60534-4)
Pipe connection	External thread to ISO 228
Stroke	See «Type overview»
Valve closing point	Up (▲)
Installation position	Upright to horizontal (in relation to the stem)
Maintenance	Maintenance-free
Fitting	Red casting brass Rg5
Valve cone	Stainless steel
Valve stem	Stainless steel
Valve seat	Red casting brass Rg5 / Niro (bypass)
Stem gland seal	EPDM O-Ring
Dimensions and weights	See «Dimensions and weights», page 3
See the Complete overview «The	e complete range of water solutions»

Dimensions / Weights

Motorizing

Materials



Safety notes



- This globe valve has been designed for use in stationary heating, ventilation and air conditioning systems and is not allowed to be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- It may only be installed by suitably trained personnel.
 All applicable legal or institutional installation regulations must be complied with.
- The valve does not contain any parts that can be replaced or repaired by the user.
- The valve is not allowed to be disposed of as household refuse. All locally valid regulations and requirements must be observed.
- The recognized rules should be applied when determining the flow characteristic of final controlling elements.

Product features

Mode of operation

The globe valve is operated by an NV series linear actuator. The linear actuators are controlled by a standard modulating or 3-point control system and move the cone of the valve, the throttling device, to the opening position dictated by the control signal.

Flow characteristic

An equal-percentage flow characteristic is produced by profiling the valve cone.

Manual operation


On the NV linear actuator, the valve stem can be actuated manually using a hexagonal key.

Installation notes

Recommended mounting positions

The globe valve may be mounted either **vertically** or **horizontally**.

It is not permissible, mounting the globe valve with the stem pointing downwards.



Water quality requirements


- The water quality requirements specified in VDI 2035 must be adhered to.
- Globe valves are relatively sensitive control devices. In order to ensure a long service life, it is advisable to fit strainers.

Maintenance

- The globe valves and linear actuators are maintenance-free.
- Before any kind of service work is carried out on actuator sets of this type, it is essential to
 isolate the linear actuator from the power supply (by unplugging the power lead). Any pumps in
 the part of the piping system concerned must also be switched off and the appropriate isolating
 fittings closed (allow everything to cool down first if necessary and reduce the pressure in the
 system to atmospheric).
- The system must not be returned to service until the globe valve and the linear actuator have been properly reassembled in accordance with the instructions and the pipework has been refilled in the proper manner.

Direction of flow

The direction of flow, specified by an arrow on the housing, is to be complied with, since otherwise the globe valve can be damaged.





Accessories

Description


Mechanical acessories

Stem heating ZH24-1 (45 W)

Pipe connector ZH45..

Dimensions and weights

Dimensional drawings



DN	G	L	Н	В	X 1)	Y 1)	Weight
[mm]	["]	[mm]	[mm]	[mm]	[mm]	[mm]	[kg]
15	1 1/8	80	46	65	350	100	1.2
20	1 1/4	90	46	65	350	100	1.3
25	1 1/2	110	52	66	350	100	1.6
32	2	120	56	67	350	100	2.2
40	2 1/4	130	65	72	350	100	2.8
50	2 3/4	150	65	75	350	100	3.9

¹⁾ Minimum distance with respect to the valve centre.

Further documentations

- Complete overview «The complete range of water solutions»
- · Data sheets actuators
- Installation instructions for globe valves and/or actuators
- Notes for project planning (hydraulic characteristic curves and circuits, installation regulations, commissioning, maintenance etc.)

 $^{^{\}rm 2)}$ The actuator dimensions can be found on the respective actuator data sheet.